

# Laminate End Splash Installation

**IMPORTANT:** We have taken extra steps to package the end splash, helping to ensure that it arrives free from damage. Inspect the splash as soon as possible and prior to installation. Check all dimensions, and test fit the end splash.

## Materials Required

Pencil  
Color Match Caulk  
Caulk Gun  
Rags / Shop Towels

## Applying End Splash

1. Clean countertops well where the end splash will be installed. Surface must be free of dust, dirt, oil and other substances. Ensure the area is completely dry before next step.
2. Knead the color-match caulk before using.
3. Place the end splash and trace along the top where it meets the wall and countertop with a marking utensil.
4. Remove from the planned location and dab dime sized areas of color-match caulk along the back and underside of the end splash.
5. Place the end splash in the traced location ensuring that it lines up.
6. Press firmly against the side splash to ensure that it seats in the caulk.
7. Place a 1/8" bead of color-match caulk between the top of the end splash and wall, and between the backsplash and the countertop to seal from moisture.
8. Using moderate pressure and a damp finger, remove excess caulk.

NOTE: End splashes are a wood based product and are subject to board movement.

NOTE: Caulk will shrink as it cures

