

Laminate Faucet Installation

IMPORTANT: Please read through the entire instructions before starting your installation. Failure to follow these instructions could possibly void the warranty on your countertops. CustomCraft Countertops® Laminite warranty does not cover abuse or accidental damages. For more information visit us at www.midwestmanufacturing.com

Materials Required

- A Pencil / Marker
- B Tape Measure
- C Drill
- D Silicone



Following the faucet manufacturer specifications, determine the location of the faucet on sink's faucet deck or countertop and mark it with a pencil/marker. (Fig 1)

Drill a hole on the mark in the diameter specified by the faucet manufacturer. Any additional holes (i.e. soap dispenser) should be drilled at this time to the right or left of the faucet hole. (Unless otherwise specified by the faucet manufacturer.) (Fig 2)

Clean debris around the drilled hole and apply clear silicone inside of the hole. (Fig 3)

Install the faucet according to the manufacturer's instructions. (Fig 4)

Clean debris from the sinks surface and wipe clean with soap and water. (Fig 5)

